


How to use the Swift TV remote.



Scan the QR code for more user guides.

swift

Press the  to go to the **Home** screen.

Use the four **arrows** to move left, right, up and down.

Press these buttons for Volume Up and Down.

To turn ON or OFF the TV press the **Power** button on the remote.

Press **OK** to make a choice.

To scroll channels, press P+ and P- (Channel Up and Down).

To watch Live TV press the channel number.

